

PRO-VISION

Video Systems

5.5" CRT Monitor: Operating / Set-up Instructions

- Rear Camera is always connected to port C1 – rear of monitor.
- Second Camera is always connected to port C2 – rear of monitor.

Single Camera Set-up

* Power button must be on – green indicator light will glow.

Desired Function:

- On Always

Set the front monitor buttons to the following:

- Camera = C1
- Mode = Manu

Desired Function:

- On In Reverse ONLY *See Note

Set the front monitor settings to the following:

- Camera = C1
- Mode = Auto

Dual Camera Set-up

* Power button must be on – green indicator light will glow.

Desired Function:

- Second Camera on always and rear camera on in reverse. *See Note

Set the front monitor settings to the following:

- Camera = C2
- Mode = Manu

Note:

The *brown wire* from the power harness must be connected to reverse gear switch for auto channel switching to occur.